_ Layout Form ____

				•		•	vithin 4 hours, or send ns or feet / inches.
When do you	need this layout	by? Date	Time				
1. Measured L	uff	Measured F	oot	Boat	S	ize	Year
2. # of control	lines planned. 2	3 _	4	_ 5	Мо	re lines cost mor	e, work better.
•	ngths: Spreade center of mast tro		•	•	ler 3	Spreader 4	·
Ways to measu	ure spreader leng	gths:					
 Tape a yard If a single s Measure at a Check our d Accuracy no Luff hardwa hardware. W 		e lower may r heck. Manual. Jse as a doub m the tack. Ru n the head dow	ole check. In a measuring wn, but foot up	tape from the to		54A Beach Roo Tel. 203-838-0 ead. Record the	Van Breems, Inc. ad, Norwalk, CT 06855 1375 Fax 203-838-0377 positions of all the luf surement is for a slide
1	,			BR5	BR6_	BR7	BR8
BR9	BR10						BR16
BR17	BR18	BR19	BR20	BR21	_ BR22	BR23	BR24
BR25	BR26	B\$27	BR28	BR29	_ BR30	BR	_
the leech pos not needed. short battens Batten 1 position	sition of the batte If there is NO ch	ens. Note the language short be	Leech length. T attens will ever 5 6	hen measure the be converted to	length of e	ach Batten. Leng	own the leech. Record of this of short batten are O under the length fo
6. Mid point gi to the luff.	irth If no	ot a full batten	sail, from cent	er of luff, measu	re from the l	uff to the leech.	Keep tape 90 degree:
7. Contact and ordering info. Your name loft				tel #		fax #	
We suggest yo	ou fill in the above	e Para 7 info,	then copy off	this form as nee	ded.		
System: 26 Need mono N Ship Method:	n, check (x) what _30 40 5 oYes If 1-day 2-d red recently	50 60 Yes, do you lay 3-c	lay Gro	und			? PO #:
	– Sail Flaking 4 co quantity needed	lor (Sabre 36	2) Brochures _		Journals	Other	
8. Your Name				_Tel		Fax	B Cś
Company					City		
Date Layout Ne	eeded						